BLG 506E – COMPUTER VISION


Project Progress Presentation


BURAK BOZDAĞ - 504211552

Recap: About the Project

Classifying Chest X-Ray Images Using CNN and Transformer Based Architectures

Comparing CNN and transformer models for classifying patients as normal or infected





Applied Processes and Methods

- ➤ TensorFlow, Keras
- > Examining Dataset
- ➤ Data Augmentation
- **≻**ViT Evaluation





Test Bench

- >AMD Radeon RX 6600 XT 8GB
- ►16 GB RAM
- >tensorflow-cpu==2.10
- >tensorflow-directml-plugin
- Enable GPU Acceleration for TensorFlow 2 with tensorflow-directml-plugin [1]



Dataset


- Chest X-Ray Images (Pneumonia) [2]
- > 5856 JPEG images (1.15 GB)
- >5216 train
- ≥16 validation
- >624 test

```
(amd_gpu) PS C:\Users\Burak\Desktop\BLG506E-CV\Project> python .\chest_xray.py
2022-12-04 12:27:44.250691: I tensorflow/c/logging.cc:34] Successfully opened of
2022-12-04 12:27:44.250771: I tensorflow/c/logging.cc:34] Successfully opened of
2022-12-04 12:27:44.252886: I tensorflow/c/logging.cc:34] Successfully opened of
2022-12-04 12:27:44.391692: I tensorflow/c/logging.cc:34] DirectML device enume
Found 5216 images belonging to 2 classes.
Found 16 images belonging to 2 classes.
Found 624 images belonging to 2 classes.
```



Data Augmentation

- \triangleright Rescale = 1/255
- ► Zoom Range = 0.1
- ➤ Rotation Range = 0.2
- ➤ Horizontal-Vertical Flip
- >224x224 WxH



ViT Evaluation

- > Callbacks:
 - ➤ Monitoring Validation Loss
 - ➤ Reduce LR
 - ➤ Early Stopping
 - ➤ Model Checkpoint
- ➤ ViT-B/16 architecture
- Layers: Input, Conv2D, Reshape, 12 x Transformer Encoders, Normalization, Lambda, Dense
- ➤ Pre-trained model with ImageNet 2012


ViT Evaluation

➤ Optimizer: Adam

Loss: Binary Cross-Entropy

➤ Max. # of 50 Epochs

$$H_p(q) = -\frac{1}{N} \sum_{i=1}^{N} y_i \cdot log(p(y_i)) + (1 - y_i) \cdot log(1 - p(y_i))$$



```
Epoch 2/50
Epoch 3/50
Epoch 4/50
Epoch 5/50
Epoch 6/50
Epoch 7/50
Epoch 8/50
Epoch 9/50
Epoch 10/50
Epoch 11/50
652/652 [==========================] - ETA: 0s - loss: 0.0785 - accuracy: 0.9688
Epoch 11: ReduceLROnPlateau reducing learning rate to 2.499999936844688e-05.
Epoch 12/50
Epoch 13/50
Epoch 14/50
Epoch 15/50
Epoch 15: early stopping
```

Results

➤0: Healthy

▶1: Pneumonia

>Accuracy: 0.93

	precision	recall	f1-score	support	
0	0.97	0.83	0.89	234	
1	0.91	0.98	0.94	390	
accuracy			0.93	624	
macro avg	0.94	0.91	0.92	624	
weighted avg	0.93	0.93	0.93	624	
() DS			1016565	0.00	
(amd_gpu) PS	C:\Users\Bur	ak\Deskto	p\BLG506E-	CV\Project>	<pre>python .\chest_xray.py</pre>

Remaining Work

- ➤ Setting up a traditional CNN model
- ➤ Comparing CNN and ViT
- ➤ Multi-class classification (viral-bacterial infection)
- ➤ Merging other datasets (Tuberculosis, COVID-19)

References

[1] "Enable GPU Acceleration for TensorFlow 2 with tensorflow-directml-plugin," *DirectML Plugin for TensorFlow 2 | Microsoft Learn*, 2022. [Online]. Available: https://learn.microsoft.com/en-us/windows/ai/directml/gpu-tensorflow-plugin.

[2] D. S. Kermany, et al., *Identifying Medical Diagnoses and Treatable Diseases by Image-Based Deep Learning*, 2018. [Online]. Available: https://www.cell.com/cell/fulltext/S0092-8674(18)30154-5.